PRINTING INSTRUCTIONS FOR GRAPHTEC 6000-60

BEFORE YOU START

- Students may only print if they have pre-paid
- Place receipts in purchase binder
- Make note of vinyl type and quantity in inventory log

STEP 1 - MOUNT PLOTTER

- Turn on Graphtec button on left side of machine
- Load material by feeding through back, and lowering stabilizer arm (on right) Screen menu will ask you to select Roll or sheet.
 - Roll front edge or Sheet. Sensor in head will measure size
- DO NOT CHANGE SETTINGS on machine.

STEP 2 - CHECK IMAGE FILE

- Open Adobe Illustrator
- Open File
- Check size
- Go to FILE>Cutting Master 3> Send to Cutting Master 3

STEP 3 - CUTTING MASTER 3 SETTINGS

CUTTING MASTER 3 MENU - TOP RIGHT



PAGE | WEED SETTINGS | TILING | MATRIX COPIES | CONFIGURE CUT JOB | CUTTERS

-PAGE

-In order for the material size to be accurate, select Automatic (Poll Size) from top right menu. This is the reading from the sensor.

- -Paper Size -Cutter senses roll/sheet dimensions
- -Job Size Change scale by percentage if necessary
- -Orientation Rotate to fit image on media if necessary
- -Mirror Turn on for Intaglio or interior mounting on glass surface

-WEED SETTINGS

- -Show weed border > ON
- -Weed lines > Padding (adjust the space between the vector/image line and the cutting line), Toggle to find best (Recursive/ Horizontal/ Vertical)

-TILING

-DO NOT CHANGE

-MATRIX COPIES

-Adjust to fit copies on media

-CONFIGURE CUT JOB

-DO NOT CHANGE

CUTTERS

- -Check cutter status
- -Once cutter is ready select send button at bottom of window

STEP 4 - REMOVE CUT VINYL

- -Release Sheet/Roll from cutter
- -Use scissors to cut finished work from roll/sheet leaving a 1" margin after cut line.

CUT THE ENTIRE WIDTH OF THE MATERIAL

STEP 5 - WEEDING

 Students must weed their own cutting jobs using EZ weeder tool to carefully lift excess material from surface.

STEP 6 - MASKING

- Line work up on masking table.
- Pull masking down to bottom edge of material and gently smooth over surface
- Trim at top edge, trim around finished work so no adhesive is overhanging surface.

STUDENTS MUST PURCHASE THEIR OWN 3M SMOOTHERS FROM THE STORE \$2.50